FDL-390CV

SERVICE MANUAL

AEP Model



SPECIFICATIONS

TV standard Colour system

CCIR TV standard PAL

Channel coverage

VHF-L E2-E4, S01-S1

VHF-H S2-S10, E5-E12, S11-S20

UHF E21-E68

Antenna Display

VHF/UHF telescopic antenna TN LCD/TFT active matrix method

Total picture-element number: 89,505 Effective picture-element ratio: more than

99.99%

Picture size

3-inch picture measured diagonally

Speaker

Input

Weight

77 mm (3 inches) dia.

EXT ANT: minijack, impedance 75 ohms AUDIO/VIDEO IN: tripolar minijack,

Impedance Audio 47 kilohms/Video 75 ohms EAR: minijack, impedance 8-300 ohms

Output Power requirement

9 V DC, See page 3 "Power sources". See page 3 "Power sources".

Battery life

5.8 W (9 V DC)

Power consumption

Dimensions

Approx. 208 \times 116.5 \times 72.5 mm (w/h/d) (8 1 /₄ \times 4 5 /₈ \times 2 7 /₈ inches) incl. projecting parts

Approx. 1.1 kg (2 lb 7oz) incl. batteries.

Supplied accessories

AC power adaptor (1) Antenna cable (1)



Design and specifications are subject to change without notice.

FEATURES


- The LCD (Liquid Crystal Display) provides clear pictures and natural facial colour tones
- This unit receives either CCIR (VHF/UHF) or cable TV system.
- This unit is used as an AV (audio/video) monitor.
- . This unit has a powerful sound output of 500mW
- The voltage synthesizer tuning system allows easy tuning.
- Provides 8 hours of continuous operation using the six LR14 (size C) alkaline batteries.
- · An angle-adjustable stand is provided.



LCD COLOUR TV SONY®

TABLE OF CONTENTS

<u>Section</u>	$\underline{\mathit{Title}}$	<u>Page</u>	<u>Section</u>	$\underline{\mathit{Title}}$	Page
1. GENERAL			4. DIAGRAMS		
• Power Source	es	3	4-1. Block Diagr	ram	11
 Watching the 	e TV	3	4-2. Semiconduc	tor Lead Layouts	14
• Using as a M	Monitor	3	4-3. Printed Wir	ing Board	15
Connecting a	an External Antenna	3	4-4. Schematic I	Diagram	19
2. DISASSEME	BLY		5. PIN DESCR	IPTION	
2-1. Cabinet (rea	ar) Sub Assy	4	5-1. Pin Descript	tion	24
2-2. Main Board	d Assy	4			
2-3. Fluorescent	Indicator Tube	5	6. EXPLODED	VIEW	
2-4. Liquid Crys	stal Display Module	5	6-1. Main Section	on	26
3 FLECTRICA	AD HISTMENTS	6	7 FLECTRICA	I DADTS LIST	27



When you read this operating instructions, refer to the illustrations indicated in

Power Sources

Using on House Current A

Use the supplied AC power adaptor

1 Connect the AC power adaptor to a wall outlet

2 Connect the AC power adaptor to the DC IN 9V lack of this unit.

After operating this unit with an AC power adaptor, be sure to disconnect the adaptor from the mains

The power switch on this unit does not turn off the AC power adaptor

Using on the Alkaline Batteries

Insert six LR14 (size C) batteries (not supplied)

- 1 Remove the battery compartment lid at the rear 2 Lav the ribbon a
- 3 Insert the batteries with correct polarities.
- 4 Reinstall the lid.

To remove the batteries

Pull the ribbon. The batteries will come out of the compartment.

Battery replacement

When the batteries become weak, the unit's protective function will automatically cause the picture to disappear. In this case, replace all the batteries with new ones.

Battery life

You can continuously use for approximately 8 hours on the alkaline batteries, or approximately 2.5 hours on the manganese batteries. The battery life becomes short in a cold place.

Using on Car Battery

You can use the unit only in a 12 V DC car.

You need the Sony DCC-E190L car battery cord (not supplied)

1 Connect the car battery cord to the cigarette lighter socket.

2 Connect the car battery cord to the DC IN 9V lack of this unit

- Use only the supplied AC power adaptor or DCC-E130L car battery cord. Do not use any other AC power adaptor or car battery cord.
- When the unit is not to be used for a long period of time, remove the batteries to avoid unit damage caused by battery leakage and corrosion



Polarity of the plug

Watching the TV D

For your safety, do not watch the TV nor operate the controls while driving.

To watch the cable TV, connect the cable to the EXT ANT jack. 1 Set the POWER switch to ON.

2 Select the band as follows:

To watch the UHF channels, set to UHF

To watch the VHF channels, set to VHF+LOW (E2-E4) or VHF+HIGH (E5-E12).

To watch the cable TV, set to VHF+LOW (S01-S1) or VHF+HIGH (S2-S20)

The green line on the screen indicates the VHF low channels.

The blue line indicates the VHF high channels.

The red line indicates the UHF channels.

- 3 Pull out the antenna fully (not necessary for the cable TV).
- 4 Tune in the desired channel
- 5 Adjust the length and direction of the antenna (not necessary for the cable TV).
- For UHF, the receiving may be better with the short antenna.

6 Adjust the volume.

To turn off the TV

Set the POWER switch to OFF, and fold the antenna.

If the channel changes

If the power is momentarily lost because of a mechanical shock, or if the unit has passed through a tunnel, the channel may change. If this happens, tune in the desired channel

Adjusting the Picture []

For more brightness, turn the BRIGHT (brightness) control clockwise. For less brightness, turn the BRIGHT control counterclockwise For more colour intensity, turn the COLOUR control clockwise For less colour intensity, turn the COLOUR control counterclockwise

To indicate the current channel

Press the CH (channel) CALL button

The line (green for VHF low, blue for VHF high, red for UHF) appears at the position of the current channe

To listen with the earphone

Connect the Sony ME-L91D earphone (not supplied) to the EAR jack

How to Use the Stand

To watch the TV

You can adjust the stand in three angles.

To carry the unit

Using as a Monitor I

You can use the unit as a colour monitor for your VTR or video camera recorder. Connect your VTR to the AUDIO/VIDEO IN jack using the Sony AVK-715M AV cord (not supplied). Before connection, turn off the unit and the VTR.

- If the picture is distorted or noisy, move the unit away from the VTR.
- When watching TV, disconnect the plug from the AUDIO/VIDEO IN lack.

Connecting an External Antenna

Receiving will improve

Connecting the Outdoor Antenna

a to e indicate the letters in the illustration.

Connect the VHF antenna a and/or the UHF antenna b to the EXT ANT jack of this unit using the mixer c, 75-ohm coaxial cable d (not supplied), and antenna cable e

Connecting the Car Antenna

Connect the car antenna (not supplied) to the EXT ANT jack of this unit.


This instruction manua section S extracted from


FDL-390CV

SECTION 2 DISASSEMBLY


Note: Follow the disassembly procedure in the numerical order given.


2-1. CABINET (REAR) SUB ASSY











SECTION 3 ELECTRICAL ADJUSTMENTS

CAUTIONS

- 1. Make adjustment in sequence as described.
- 2. Power supply voltage is $+9.0 \pm 0.1 \text{V}$ (DC jack end) unless otherwise specified. Power supply shall not be input overlapped.
- 3. Check the error in waveform and screen for adjustment.
- 4. Measure a fluorescent tube and an Liquid Crystal Display module (LCD) device by connecting them with the main board.
- Unless otherwise specified, input the color bar signal, etc. from AUDIO/VIDEO IN jack (J501) by using AV-cord (AVK-715M, etc.) to intercept the internal TV detection output.

Also, usually use monochromatic gradation wave monoscope with chroma signal and burst signal OFF.

- 6. Measuring instruments
 - PAL pattern generator
 - Digital multitester
 - Oscilloscope
- 7. Modes of SW, VR

VOLTAGE ADJUSTMENT

Procedures:

- 1. Connect a digital multitester between TP605 (\pm 4.8V) and TP602 (GND) on the main board, and then adjust RV601 so that the reading of the voltage is \pm 4.85 \pm 0.05V.
- 2. Connect a digital multitester between TP606 (-8V) and TP602 (GND), and then adjust RV602 so that the reading of the voltage is $-8.0\pm0.1V$.
- 3. Connect a digital multitester between TP607 (\pm 4.4V) and TP602 (GND), and then adjust RV603 so that the reading of voltage is \pm 4.4 $\pm^{0.05}_{0.05}$ V.


WAVEFORM CHECK/COM ADJUSTMENT

Procedures:

1. Y signal check (H cycle)

Input the color bar signal from AUDIO/VIDEO IN jack (J501).

Connect an oscilloscope to TP303 (Y) to check if the waveform is as shown in the following figure.




2. SYNC signal check (H cycle)

Connect an oscilloscope to TP304 (SYNC) to check if the waveform is as shown in the following figure.



3. Color burst signal check (H cycle)

Connect an oscilloscope to TP305 (CHROMA) to check if the waveform is as shown in the following figure.



4. H pulse check (H cycle)


Connect an oscilloscope to TP301 (H PULSE) to check if the waveform is as shown in the following figure.



5. COM signal check/adjustment (2H cycle)


Connect an oscilloscope to TP302 (COM) to check if the waveform is as shown in the following figure.

Turn and set RV309 at the position where the contrast is the most distinction LCD. (DC level of figure are reference)




COMMON VOLTAGE ADJUSTMENT

— Adjustment with a jig — connection :



Procedures:

- 1. Apply the photo detector unit of COMMON voltage adjustment jig (J-6082-024-A) to the LCD. At this time, turn the LCD downward to avoid interference of external light.
- 2. Connect an oscilloscope to the common voltage adjustment jig.
- 3. Input the monochromatic gradation wave from AUDIO/VIDEO IN jack (J501).
- 4. Turn RV301 to check if the waveform is as shown in the figure below. When flicker waveform is not output, check the applying state of the photo detector unit and the state of external light and then turn the BRIGHT VR (RV305).
- 5. Minimize the amplitude of flicker waveform with RV301.



* When there is no COMMON voltage adjustment jig, make the following simple adjustment.

- Simple adjustment -

Procedure:

- 1. Input the monochromatic gradation wave from AUDIO/VIDEO IN jack (J501).
- Turn and set RV301 at the position where the contrast is the most distinction LCD. Magnify LCD with a magnifier, etc., up to the level where the pixels of LCD can be obtained, and adjust RV301 so that the flickers are minimum while watching the flickers.

BRIGHT VOLTAGE PREADJUSTMENT

Procedures:


- 1. Input the color bar from AUDIO/VIDEO IN jack (J501).
- 2. Connect a digital multitester between TP307 (BRT) and TP311 (GND) and adjust BRIGHT VR (RV305) so that the reading of the voltage is $+1.85\pm0.02$ V.

G BIAS/B BIAS/R BIAS ADJUSTMENTS

Procedures:

- 1. Turn COLOUR VR (RV307) to minimum (monochrome).
- Connect a ceramic capacitor (10000pF) between TP305 (CHROMA) and TP311 (GND).
- 3. Input the monochromatic gradation wave from AUDIO/VIDEO IN jack (J501).
- 4. Connect an oscilloscope to TP308 (G), and adjust RV306 so that DC level for the pedestal unit of positive polarity G signal is -4.0 ± 0.1 V as shown in the following figure. (G bias adjustment)
- 5. Connect an oscilloscope to TP310 (B), and adjust RV310

- so that DC level for the pedestal unit of positive polarity B signal is -4.0 ± 0.1 V as shown in the following figure. (B bias adjustment)
- 6. Connect an oscillospe to TP309 (R), and adjust RV311 so that DC level for the pedestal unit of positive polarity R signal is -4.0 ± 0.1 V as shown in the following figure. (R bias adjustment)




CONTRAST/B GAIN/R GAIN ADJUSTMENTS

Procedures:

- Input the monochromatic gradation wave from AUDIO/ VIDEO IN jack (J501).
- 2. Connect an oscilloscope to TP308 (G), and adjust RV302 so that the DC voltage the positive polarity G signal of white (100%) is -0.7 ± 0.1 V as shown in the following figure. (Contrast adjustment)
- 3. Connect an oscilloscope to TP310 (B), and adjust RV301 so that the DC voltage the positive polarity B signal of white (100%) is -0.7 ± 0.1 V as shown in the following figure. (B gain adjustment)
- 4. Connect an oscilloscope to TP309 (R), and adjust RV303 so that the DC voltage the positive polarity R signal of white (100%) is -0.7 ± 0.1 V as shown in the following figure. (R gain adjustment)

Note: Adjustment the each RV so that the waveform of * part is convex to upper side as shown in the following figure.




WHITE BALANCE ADJUSTMENT

Procedures:

- 1. Connect the channel 1 of an oscilloscope to TP308 (G). Turn the BRIGHT VR (RV305) counterclockwise to darken the screen. (until the minimum value which can be observed by the oscilloscope is reached.)
- 2. With the oscilloscope connected to TP308 (G), connect


TP309 (R) to the channel 2.

- 3. Turn RV303 and adjust the DC voltage of the positive polarity R signal in the white direction (100%) to the DC voltage of the positive polarity G signal in the white direction (100%).
- 4. With the oscilloscope connected to TP308 (G), connect TP310 (B) to the channel 2.
- 5. Turn RV301 and adjust the DC voltage of the positive polarity B signal in the white direction (100%) to the DC voltage of the positive polarity G signal in the white direction (100%).



- 6. Connect a digital multitester to TP307 (BRT). Turn RV305 clockwise and brighten the screen so that the reading of the voltage value is + 1.85 \pm 0.1 V.
- 7. Connect TP308 (G) to the channel 1 and TP309 (R) to the channel 2 of the oscilloscope.
- 8. Turn RV311 and adjust so that the positive and negative polarity R signal overlaps the positive and negative polarity G signal * (the DC level of each tone is matched between these signals).
- 9. With the oscilloscope connected to TP308 (G), connect TP310 (B) to the channel 2.
- 10. Turn RV310 and adjust so that the positive and negative polarity B signal overlaps the positive and negative polarity G signal ** (the DC level of each tone is matched between these signals).
- *, * *: The positive and negative polarity signal may not be matched with the corresponding signal simultaneously due to variations. (See figures (a) and (b).)

 In this case, adjust to the average positions of the positive and negative positions. (See figure (c).)



- 11. Input the monochromatic gradation wave or monoscope signal from AUDIO/VIDEO IN jack (J501).
- 12. Turn the BRIGHT VR (RV305) and verify that there is only monochrome display with no colors in all of the maximum and minimum positions. If any color is present, readjust RV303 (R GAIN) and RV301 (B GAIN).


Note: It should be noted that when BRIGHT is darkened, color tends to appear.

- 13. Remove a ceramic capacitor to connected by G bias adjustment.
- 14. Input the color bar signal from AUDIO/VIDEO IN jack (J501).
- 15. Turn the BRIGHT VR (RV305) to maximum and turn the COLOUR VR (RV307) to minimum and verify that the screen changes normally. Lastly, place the respective controls in their center positions.

ANTI PAL ADJUSTMENT-1

Procedures:

- Input the color bar signal from AUDIO/VIDEO IN jack (1501).
- 2. Connect a oscilloscope to TP308 (G).
- 3. Preadjust RV308 and CV302 as shown in the following figure (A).
- 4. Turn the COLOUR VR (RV307) and BRIGHT VR (RV305) to maximum.
- 5. Turn the T301 and RV308 and adjust so as completely overlaps on color bar signal (red (Ω A) and blue (Ω B) portions) by 2V/div. range of oscilloscope as shown in the following figure (B).




Note: Adjust so as completely overlaps on red and blue portions of color bar signal by 2V/div. range of oscilloscope.

ANTI PAL ADJUSTMENT-2

Procedures:

- 1. Input the philips pattern signal from the AUDIO/VIDEO IN jack (J501).
- 2. Turn CV302 and adjust so that the color of the anti PAL signal portions is dimmest on the screen.



Note: Anti PAL adjustment-1 and -2 is as each effect, repeat adjust few times.

VIF ADJUSTMENT/AFT ADJUSTMENT

Note: These adjustments are not performed usually.


Never touch L204 and L205 of adjustment devices.

While, only when L204, L205 or capacitors around L204, L205 have been replaced, make the following simple adjustment.

- Simple adjustment -

Procedures:

- Connect a ceramic capacitor (10000pF) between TP207 (SAW IN) and TP209 (GND).
- Connect a jumper wire between TP210 (MUTE) and TP209 (GND).
- 3. Input the monochromatic gradation wave from TP101 (ANT IN).
- 4. Connect an oscilloscope to Q301 emitter.
- 5. Adjust L204 so that the SYNC signal is maximum (VIF adjustment).
- Turn and L205 to adjust the level so that the screen is colored from monochrome without breaking of Y signal. (AFT adjustment) (Reference value: Vp-p of burst signal is about 60mV.)
- 7. Receive the broad casts of each channel, and check if the screen is colored after the synchronism is stopped with each channel.
- 8. Remove a ceramic capacitor and jumper wire to connected by items 1 and 2.



AGC ADJUSTMENT

Procedures:

- 1. Receive the TV broadcast.
- 2. Turn and adjust RV201 so that the snow noise is shown.
- 3. Reversely turn and set RV201 to the point where the snow noise disappears.
- 4. Receive the broadcast for each channel, and check if there is beat, image distortion of snow noise caused by mixed demodulation.
- 5. If any beat, image distortion of snow noise are observed, adjust RV201 again.

TUNING ADJUSTMENT

Procedures:

- 1. Short S104 (CH CALL).
- 2. Set S101 (BAND) to the VHF LOW side to check with the screen if the display bar was turned green.
- 3. Receive the broadcast of 2CH by pushing S102 (CHANNEL -) or S103 (CHANNEL +).
- 4. Adjust RV104 so that the display bar is corresponded to the position of 2CH.
- 5. Receive the broadcast of S1CH, and adjust RV101 so that the display bar is corresponded to the S1CH.

Note: Since the items 4 and 5 will interfere each other, the adjustment is necessary for 2 to 3 times.

- 6. Receive the broadcasts of 2 to S1CH, and check if the display bar is corresponded to each channel.
- 7. Set S101 (BAND) to the VHF HIGH side to check with the screen if the display bar was turned blue.
- 8. Receive the broadcast of S2CH by pushing S102 (CHANNEL+).
- 9. Adjust RV105 so that the display bar is corresponded to the position of S2CH.
- 10. Receive the broadcast of S20CH, and adjust RV102 so that the display bar is corresponded to each channel.


Note: Since the items 9 and 10 will interfare each other, the adjustment is necessary for 2 to 3 times.

- 11. Receive the broadcasts of S2 to S20CH, and check if the display bar is corresponded to each channel.
- 12. Set S101 (BAND) to the UHF side to check with the screen if the display bar was turned red.
- 13. Receive the broadcast of 21CH, and adjust RV106 so that the display bar is corresponded to the position of 21CH.
- 14. Receive the broadcast of 68CH, and adjust RV103 so that the display bar is corresponded to the position of 68CH.

Note: Since the items of 13 and 14 will interfere each other, the adjustment is necessary for 2 to 3 times.


- 15. Receive the broadcasts of 21CH to 68CH, and check if the display bar is corresponded to the position of each channel.
- 16. Disconnect the S104 shorted in the above item 1.


Adjustment Location: main board





SECTION 4 DIAGRAMS

4-1. BLOCK DIAGRAM













4-2. SEMICONDUCTOR LEAD LAYOUTS










FDL-390CV FDL-390CV










Waveforms




Note:


- All capacitors are in µF un 50WV or less are not indi and tantalums.
- All resistors are in Ω and specified.
- % : indicates tolerance.

Note: The components iden line with mark $\stackrel{\wedge}{M}$ are Replace only with part

- B+ Line
- === : B- Line
- adjustment for reparations adjustment for reparations and the second secon
- Power voltage is dc 9V and fe from external power voltage jo
- Voltage and waveforms are of no-signal (detuned) conditions no mark: VHF • LOW
 - (): UHF
- Voltages are taken with a V Voltage variations may be tion tolerances.
- Waveforms are taken with a Voltage variations may be
- tion tolerances.Circled numbers refer to wa



Waveforms



Note:

- 50WV or less are not indicated except for electrolytics and tantalums.
- \bullet All resistors are in Ω and $^{1}\!/_{\!4}\,W$ or less unless otherwise specified.
- %: indicates tolerance.

Note: The components identified by mark A or dotted line with mark A are critical for safety.

Replace only with part number specified.


- : B+ Line
- --- : B- Line
- adjustment for repair
- Power voltage is dc 9V and fed with regulated dc power supply from external power voltage jack.
- Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions. no mark: VHF · LOW

): UHF


- \bullet . Voltages are taken with a VOM (Input Impedance 10M \odot) Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.

• IC Block Diagrams


IC601 CX20159



IC103 AN5707NS



IC201 TA8805F



-23-

SECTION 5 PIN DESCRIPTION

5-1. PIN DESCRIPTION

• IC301 M52003AFP

Pin No.	Pin Name	Pin Description
1	NC	
2	APC FILTER	This pin determines the APC time constant of VCXO.
3	VCXO-OUT	Output of VCXO oscillator.
4	VCXO-MONI	This pin provides monitor output of VCXO oscillator. This is open emitter output.
5	VCXO-IN-1	Feedback input to VCXO generator.
6	VCXO-IN-2	Phase Delayed input of the signal from Pin ⑤.
7	CHROMA DEMODULATION INPUT	Input pin for the color difference demodulator for B-Y signal.
8	CHROMA DEMODULATION INPUT	Input pin for the color difference demodulator for R-Y signal.
9	SECAM-IN	This pin receives output of the color difference decoder for SECAM B-Y. When the color killer is activated, the internal switch will select the SECAM signal side.
10	SECAM-IN	This pin receives output of the color difference decoder for SECAM R-Y.
11	PICTURE QUALITY ADJUST- MENT V	Picture Quality Adjustment pin. Increase the voltage to have sharper picture. Decrease it to have more soft picture.
12	CLAMP VOLUME	Used to adjust so that the internal signal is matched with the external RGB signal in the clamp level.
13	EXTERNAL B INPUT	External B Signal input. This input is $0.8V_{P-P}$ standard.
14	GAIN-B	Used to adjust the gain of B signal to ensure white balance. This input is 3.5V standard. Increase the voltage to reduce the gain.
15	EXTERNAL G INPUT	External G Signal input.
16	EXTERNAL R INPUT	External R Signal input.
17	CONTADJ.	Used to adjust the contrast of the internal signal. Increase the voltage to have higher contrast. Decrease it to have lower contrast.
18	GAIN-R	Used to adjust the gain of R signal to ensure white balance.
19	AGC-LEV.	Used to set the point at which AGC operates.
20	AGC-FIL1	AGC Filter pin.
21	AGC-FIL2	AGC Filter pin.
22	Y-IN	Luminance Signal Input pin. Pedestal clamp is applied. This input is $0.5V_{P-P}$ standard and comes in as synchronized negatively.
23	$-V_{EE}$	Connection pin for -7.5 V power.
24	AGC-LEVOUT	This pin outputs the point at which AGC operates. When AGC operates, the voltage will be reduced.
25	V _{cc}	Connection pin for +4.5V power for the interface unit.
26	INTERNAL/EXTERNAL SELECT	Used to switch between the internal and external signals. Set this pin "High" to select external signal. Set it to "Low" to select internal signal.
27	H/P-IN	Input pin for Synchronizing signal from an external source. When used simultaneously with synchronous separation output, this signal must rise earlier than the output.
28	REVERSE	Used to control the reverse polarity of output. Set this pin "High" to have normal white. Set it "Low" to have normal black.
29	SYNCHRO SEPARATE INPUT	Synchronous Separation input. This input is $1V_{P-P}$ video signal as synchronized negatively.
30	ON BURST CONSTANT	Time Constant which determines the width of the burst gate. The burst gate pulse having the time determined by this constant is generated at the trailing edge of synchronous separation output.

-24-

Pin No.	
31	REVE
32	COM.
33	COM.
34	SYNC
35	B. CL.
36	G. CL.
37	R. CL.
38	BRIGI
39	γ-ADJ
40	GND
41	RSU
42	GSU
43	BSU
44	RF.
45	R. SIG
46	GF.
47	G. SIG
48	BF.
49	B. SIG
50	F. B. C
51	H. D
52	KILLE
53	$-V_{EE}$
54	CHRO
55	KILLE
56	ACC F
57	COLO
58	ACC-O
59	BURS?
60	V_{cc}

n emitter output.
AM B-Y. When
CAM signal side.
CAM R-Y.
sharper picture.
ernal RGB signal
1
his input is 3.5V
W. 11.
voltage to have
voltage to have
input is $0.5V_{P-P}$
GC operates, the
•
nis pin "High" to
n used simultane-
earlier than the
" to have normal

as synchronized

burst gate pulse trailing edge of

Pin No.	Pin Name	Pin Description
31	REVERSE INPUT	Output Reversing Pulse input. This reverses common and RGB outputs at the same time. The polarity of RGB output depends on reverse polarity control.
32	COM. OUT	Common Electrode Drive Output pin.
33	COM. DRIVE	Used to set the amplitude of common electrode drive output.
34	SYNCHRO SEPARATE OUTPUT	Synchronous Separation Output pin. This is open collector output and is synchronized positively. A load resistor should be connected to use this output.
35	B. CLAMP	Connection pin for B signal clamp capacitance.
36	G. CLAMP	Connection pin for G signal clamp capacitance.
37	R. CLAMP	Connection pin for R signal clamp capacitance.
38	BRIGHT-ADJ.	Brightness Adjustment pin. Increase the voltage to have whiter picture.
39	γ-ADJ.	Used to set the gamma amount of the gamma amplifier. Connect this pin to the power when gamma amplifier is not required.
40	GND	Grounding pin. This pin should be connected to GND.
41	RSUB BIAS	Used to set the bias amount of R signal.
42	GSUB BIAS	Used to set the bias amount of G signal.
43	BSUB BIAS	Used to set the bias amount of B signal.
44	RF. BIN	Pin for DC Feedback of R output. R output is integrated and then input to this pin This pin should be connected to $-V_{\text{EE}}$ when not used.
45	R. SIGOUT	R Signal Output pin. The inverted signal is output.
46	GF. BIN	Pin for DC Feedback of G output.
47	G. SIGOUT	G Signal Output pin.
48	BF. BIN	Pin for DC Feedback of B output.
49	B. SIGOUT	B Signal Output pin.
50	F. B. CENTER LEVEL	Output Feedback Reference Voltage pin. When this voltage is varied, the center voltage of output is varied. This pin should be grounded with the capacitance for stabilization.
51	H. DIN	This pin inputs the HD signal which drives the flip flop for line pulse generation. The F/F changes at the rising edge of HD.
52	KILLER OUT	Killer Signal output. When the killer is activated, this output will be High.
53	$-\mathrm{V}_{\mathtt{EE}}$	Connect this pin to -7.5 V power. It has the same potential with Pin 3 .
54	CHROMA IN	Chroma Signal Input pin. This input is burst 100mV _{P-P} standard.
55	KILLER FILTER	Killer Filter Connecting pin.
56	ACC FILTER	Used to set the ACC time constant.
57	COLOR-CONTROL	Used to control the color level. Increase the voltage to increase the color satura tion.
58	ACC-OUT	This pin outputs chroma signal under ACC. This output is sent through 1H delay line and then input into the demodulator. Burst removed signal is output.
59	BURST CLEANING	Connecting pin for the burst cleaning coil. The demodulation angle is adjusted by adjusting this coil.
60	V _{cc}	This pin is connected to +4.5V power. Video Chroma System Power pin.

-25-

SECTION 6 EXPLODED VIEW

NOTE:

15

16


4-030-639-01 BUTTON, TUNING +/-

- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Color Indication of Appearance Parts Example KNOB, BALANCE (WHITE)...(RED)

Parts Color Cabinet's Color

• Hardware(#mark) list is given in

the last of this parts list.



--26

1-544-548-11 SPEAKER (8CM)

SECTION 7 ELECTRICAL PARTS LIST

MAIN

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- -XX, -X mean standardized parts, so they may have some differences from the original one.
- **CAPACITORS**

- RESISTORS All resistors are in ohms METAL: Metal-film resistor METAL OXIDE: Metal Oxide-film resistor
- F: nonflammable
 COILS
 uH: ,,H
 SEMICONDUCTORS In each case, u: μ , for example: uA...: μ A..., uPA...: μ PA..., uPB...: μ PB..., uPC...: μ PC..., uPD...: μ PD....

The components identified by mark \bigwedge or dotted line with mark \bigwedge are critical for safety.

Replace only with part number

When indicating parts by reference number, please include the board name

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
	* A-3016-111-A	MAIN BOARD. CO	MPLETE			C208	1-164-005-11	CERAMIC CHIP	0. 47uF	_	25V
		*********	*****			C209	1-164-346-11	CERAMIC CHIP	1uF		16V
						C210	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
		PIN. CONNECTOR			ĺ	C211	1-126-603-11	ELECT CHIP	4. 7uF	20%	35V
		CABLE (WITH CO				C212	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50 V
	4-030-645-01	SPRING, HOLDER	1								
						C213	1-163-031-91	CERAMIC CHIP	0. 01uF		50 V
		< CAPACITOR >				C214	1-163-085-00	CERAMIC CHIP	2PF		50 V
						C215	1-124-779-00	ELECT CHIP	10uF	20%	16 V
C101		CERAMIC CHIP	220PF	5%	50V	C216	1-163-031-91	CERAMIC CHIP	0. 01uF		50 V
C102		CERAMIC CHIP	0. 1uF		25V	C217	1-163-009-11	CERAMIC CHIP	0. 001uF	10%	50 V
C103	1-164-346-11	CERAMIC CHIP	1uF		16V						
C104	1-163-117-00	CERAMIC CHIP	100PF	5%	50V	C218	1-163-031-91	CERAMIC CHIP	0. 01uF		50 V
C105	1-163-113-00	CERAMIC CHIP	68PF	5%	50V	C219	1-163-031-91	CERAMIC CHIP	0. 01uF		50 V
						C220	1-164-346-11	CERAMIC CHIP	1uF		16 V
C106	1-163-013-91	CERAMIC CHIP	0. 0022uF	10%	50V	C224	1-163-009-11	CERAMIC CHIP	0. 001uF	10%	50 V
C107	1-163-031-91	CERAMIC CHIP	0. 01uF		50V	C225	1-164-005-11	CERAMIC CHIP	0. 47uF		25V
C108	1-126-395-11		22uF	20%	16V						
C109		CERAMIC CHIP	0. 01uF		50V	C226		CERAMIC CHIP	0. 47uF		25V
C110	1-163-135-00	CERAMIC CHIP	560PF	5%	50V	C241		CERAMIC CHIP	47PF	5%	50 V
						C301	1-126-205-11		47uF	20%	6. 3
C111	1-126-603-11		4. 7uF	20%	35V	C302		CERAMIC CHIP	43PF	5%	50 V
C121		CERAMIC CHIP	0. 01uF		50V	C303	1-164-346-11	CERAMIC CHIP	1uF		16 V
C122	1-126-603-11		4. 7uF	20%	35V						
C130		CERAMIC CHIP	0. 01uF		50V	C305		TANTALUM CHIP	1uF	20%	16 V
C131	1-164-346-11	CERAMIC CHIP	1uF		16V	C306		CERAMIC CHIP	0. 0047uF	5%	50V
						C307		CERAMIC CHIP	680PF	5%	50 V
C191		CERAMIC CHIP	0. 1uF		25V	C308		CERAMIC CHIP	15PF	5%	50 V
C192		CERAMIC CHIP	0. 1uF		25V	C309	1-163-115-00	CERAMIC CHIP	82PF	5%	50 V
C193		CERAMIC CHIP	0. 1uF		25V						
C201		CERAMIC CHIP	0. 001uF	10%	50V	C310		CERAMIC CHIP	0. 001uF	10%	50 V
C202	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V	C311		CERAMIC CHIP	0. 001uF	10%	50 V
						C312		CERAMIC CHIP	33PF	5%	50 V
C203		CERAMIC CHIP	120PF	5%	50V	C313		CERAMIC CHIP	56PF	5%	50 V
C204		CERAMIC CHIP	120PF	5%	50V	C314	1-163-021-91	CERAMIC CHIP	0. 01uF	10%	50 V
C205		CERAMIC CHIP	0. 0068uF	10%	50V						
C206		CERAMIC CHIP	33PF	5%	50V	C315		CERAMIC CHIP	0. 01uF	10%	50 V
C207	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C316		CERAMIC CHIP	0. 01uF		50 V
						C317	1-163-021-91	CERAMIC CHIP	0. 01uF	10%	50 V

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description		R	lemark
C318	1-163-031-01	CERAMIC CHIP	0. 01uF		50V	C414	1-124-779-00	FIFCT CHIP	10uF	20%	16V
C319		CERAMIC CHIP	0. 1uF		25V	C415		CERAMIC CHIP	0. 01uF	2070	50V
C320		TANTALUM CHIP	10uF	20%	6. 3V	C416		CERAMIC CHIP	0. 0012uF	10%	50V
C321		CERAMIC CHIP	75PF	5%	50V	C417	1-126-395-11		22uF	20%	16V
C322		CERAMIC CHIP	56PF	5%	50V	C418		CERAMIC CHIP	0. 0068uF	10%	50V
0022	1 100 240 11	OLIMINO OILL	00.1	٠,٠	• • •	0410	1 100 010 00	OLIMINIO OIIII	0. 000001	107	301
C323	1-164-346-11	CERAMIC CHIP	1uF		16V	C419	1-124-120-11	FLECT	220uF	20%	25V
C324		CERAMIC CHIP	0. 01uF		50V	C420	1-126-204-11		47uF	20%	16V
C325		TANTALUM CHIP	1uF	20%	16V	C424		CERAMIC CHIP	0. 012uF	10%	50V
C326		TANTALUM CHIP	1uF	20%	16V	C425		CERAMIC CHIP	1uF	10%	16V
C327		TANTALUM CHIP	1uF	20%	16V	C426	1-126-602-11		3. 3uF	20%	50V
0021	1 100 031 00	TANTALOM OTTO		2 474		0.120	. 120 002 11	22201 01111	0. 001	20/4	301
C328	1-163-021-91	CERAMIC CHIP	0. 01uF	10%	50V	C427	1-124-779-00	FIFCT CHIP	10uF	20%	16V
C329		CERAMIC CHIP	0. 01uF		50V	C428	1-126-395-11		22uF	20%	167
C330		TANTALUM CHIP	1uF	20%	16V	C502		CERAMIC CHIP	1uF	20%	167
C331		TANTALUM CHIP	1uF	20%	16V	C601		CERAMIC CHIP	1uF		167
C332		TANTALUM CHIP	1uF	20%	16V	C602	1-126-395-11		22uF	20%	167
0002	1 100 031 00	TANTINCOM OILL		20.0		****	, 120 000 11	22241	2201	2074	101
C333	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C603	1-126-176-11	FLECT	220uF	20%	107
C334		CERAMIC CHIP	0. 001uF	10%	50V	C604		CERAMIC CHIP	0. 0033uF	10%	50V
C335		CERAMIC CHIP	0. 1uF		25V	C605		CERAMIC CHIP	0. 0015uF	10%	50V
C336		TANTALUM CHIP	10uF	20%	6. 3V	C607		CERAMIC CHIP	0. 047uF	1070	50V
C337		CERAMIC CHIP	0. 01uF	10%	507	C609	1-124-455-00		100uF	20%	167
•••	1 100 021 01				•••	****			10001	2070	
C338	1-163-021-91	CERAMIC CHIP	0. 01uF	10%	50V	C611	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C339		CERAMIC CHIP	15PF	5%	50V	C612	1-163-011-11	CERAMIC CHIP	0. 0015uF	10%	50V
C340		CERAMIC CHIP	0. 001uF	10%	50V	C613	1-126-405-11		10uF	20%	50V
C341		CERAMIC CHIP	33PF	5%	50V	C614	1-126-405-11		10uF	20%	50V
C342		CERAMIC CHIP	0. 01uF	10%	50V	C615	1-126-405-11		10uF	20%	50V
											•••
C343	1-126-207-11	ELECT CHIP	33uF	20%	4V	C616	1-126-405-11	ELECT CHIP	10uF	20%	50V
C344	1-126-204-11	ELECT CHIP	47uF	20%	16V	C617		CERAMIC CHIP	0. 0047uF	5%	50V
C345	1-126-176-11		220uF	20%	10V	C618	1-124-779-00		10uF	20%	167
C347		CERAMIC CHIP	39PF	5%	50V	C619		CERAMIC CHIP	0. 001uF	10%	50V
C348	1-163-031-91	CERAMIC CHIP	0. 01uF		50V	C620	1-124-442-00	ELECT	330uF	20%	6.3V
C349	1-163-031-91	CERAMIC CHIP	0. 01uF		50V	C621	1-163-125-00	CERAMIC CHIP	220PF	5%	50V
C352	1-163-031-91	CERAMIC CHIP	0. 01uF		50V	C622	1-163-125-00	CERAMIC CHIP	220PF	5%	50V
C353		CERAMIC CHIP	56PF	5%	50V	C623	1-163-011-11	CERAMIC CHIP	0.0015uF	10%	50V
C354	1-163-245-11	CERAMIC CHIP	56PF	5%	50V	C624	1-163-125-00	CERAMIC CHIP	220PF	5%	50V
C355	1-163-239-91	CERAMIC CHIP	33PF	5%	50V	C625	1-163-031-91	CERAMIC CHIP	0.01uF		50V
C356		CERAMIC CHIP	56PF	5%	50V	C701	1-124-570-11		220uF	20%	16V
C357		CERAMIC CHIP	120PF	5%	50V	C702	1-126-204-11	ELECT CHIP	47uF	20%	16V
C361		CERAMIC CHIP	0. 1uF		25V	C703	1-126-405-11		10uF	20%	50V
C402		CERAMIC CHIP	0. 1uF		25V	C704	1-130-771-00		0. 18uF	10%	63V
C403	1-163-022-00	CERAMIC CHIP	0. 012uF	10%	50V	C705	1-163-038-00	CERAMIC CHIP	0. 1uF		2 5 V
					45						
C404		CERAMIC CHIP	0. 1uF	4.00/	25V	C706	1-126-395-11		22uF	20%	16V
C405		CERAMIC CHIP	0.001uF	10%	50V	C707	1-164-731-11		120PF	10%	2 K V
C407	1-124-360-00		1000uF	20%	16V	C708		CERAMIC CHIP	100PF	5%	50V
C408		CERAMIC CHIP	0. 1uF	0.00/	25V	C801	1-124-147-00		47uF	20%	2 5 V
C409	1-126-603-11	I ELECT CHIP	4. 7uF	20%	35V	C802	1-124-455-00	FLECT	100uF	20%	16V
C410	1_163_020.00	CERAMIC CHIP	0. 1uF		25V	C803	1_104 147 00	ELECT	475	200	0.51
C410		CERAMIC CHIP	u. Tur Tuf		16V	C804	1-124-147-00		47uF	20%	25V
C411		CERAMIC CHIP	1uF		167	0004	1-100-001-91	CERAMIC CHIP	0.01uF		50V
C412		CERAMIC CHIP	0. 22uF		25V						
0713	1-104-222-11	I SEMANIO SHIF	v. 22UI		201						
						-					

Ref. No.	Part No.	Description	Remark 	Ref. No.	Part No.	Description		Remark
		< FILTER >		IC402 IC601	8-759-701-54 8-759-802-39	IC NJM207		
CF201	1-409-369-00	TRAP, CERAMIC 5.5MHz		10602	8-759-630-27			
CF204		FILTER, CERAMIC		_	•		•	
CF205		FILTER. CERAMIC				< JACK >		
CF301	1-579-348-11	FILTER, CERAMIC						
				J101	1-507-974-11	JACK (EXT A	NT)	
		< CONNECTOR >		J401	1-568-593-51	JACK 1P (EA	R)	
				J501			DIO/VIDEO IN)	
		PIN. CONNECTOR (SMALL TY	PE) 2P	J601	1-569-966-11	JACK, DC (D	C IN 9V)	
CN801	1-565-073-11	SOCKET, CONNECTOR 16P						
						< COIL >		
		< TRIMMER >		1001				
011000		OAD TRIBUED SODE		L201	1-410-373-31			
CV302	1-141-298-11	CAP. TRIMMER 30PF		L202	1-410-373-31			
		< DIODE >		L204	1-404-633-11			
		V DIVUL /		L205 L209	1-404-633-11 1-410-383-31			
D102	8-719-941-23	DIODE DA204U		L203	1 410-303-31	INDUCION CH	ir ivun	
D102	8-719-400-18			L301	1-410-384-31	INDUCTOR CH	IP 18uH	
D104	8-719-951-22			L302	1-410-385-11			
D108	8-719-400-18			L303	1-410-387-11			
D191	8-719-951-22			L304	1-410-383-31			
				L305	1-410-385-11			
D403	8-719-941-23	DIODE DA204U				•		
D404	8-719-400-18	DIODE MA152WK		L306	1-410-385-11	INDUCTOR CH	IP 22uH	
D601	8-719-400-20	DIODE MA152WA		L601	1-460-032-11	COIL. CHOKE	100uH	
D602	8-719-400-20	DIODE MA152WA	*	L602	1-424-298-11	COIL, CHOKE	82 u H	
D603	8-719-400-20	DIODE MA152WA		L603	1-412-032-11	INDUCTOR, C	HIP 100uH	
				L604	1-412-032-11	INDUCTOR, C	HIP 100uH	
D604	8-719-400-20							
D605	8-719-974-51			L605	1-412-032-11			
D606	8-719-106-53			L701	1-460-032-11			
D701 D702	8-719-400-18			L702	1-424-298-11	COIL, CHOKE	82uH	
DIVZ	8-719-105-82	DIODE ROS. IM-BZ				Z TRANCICTO	D .	
D703	8-719-105-82	DIODE RD5. 1M-B2				< TRANSISTO	K >	
D703	8-719-941-23			Q101	8-729-100-66	TRANSISTOR	2SC1623	
• •	5 110 541 20	D. TOE DIEVTO		0103	8-729-805-94		2SC4047	
		< DELAY LINE >		0104	8-729-805-94		2SC4047 2SC4047	
				0105	8-729-805-94		2SC4047	
DL301	1-415-649-11	DELAY LINE, 1H (ULTRASON	IC)	Q106	8-729-805-44		2SC3397	
		< FUSE >		Q110	8-729-100-66		2SC1623	
	::	PHASE MARK PROGRAMME.	44 484 446 514	0191	8-729-805-65		2SA1344	
F601 <u>A</u> .	. 1-532-777-21	FUSE, MICRO (SECONDARY)	(1. 25A/125V)	0201	8-729-200-87		2SC2714-Y	
		. 10 >		0202	8-729-805-94		2SC4047	
		< IC >		0203	8-729-805-94	TRANSISTOR	2SC4047	
10102	8-759-981-69	IC LM2904M		0204	8-729-100-66	TRANSISTOR	2SC1623	
IC103	8-759-420-88			0301	8-729-100-66		2SC1623	
IC104	8-759-234-77			0302	8-729-216-22		2SA1162-G	
IC105	8-759-234-77			0305	8-729-216-22		2SA1162-G	
IC106	8-759-234-77			0306	8-729-100-66	TRANSISTOR	2SC1623	
10001	8-759-246-18	IC TA8805F		0307	8-729-100-66	TRANSISTOR	2SC1623	
IC201 IC301 IC401	8-759-635-37 8-759-981-69			0308 0401	8-729-216-22 8-729-140-75		2SA1162-G	

Note: The components identified by mark \bigwedge or dotted line with mark \bigwedge are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description			Remark 	Ref. No.	Part No.	Description			Remark
Q404	8-729-100-66	TRANSISTOR	2SC1623			R210	1-216-059-00	METAL CHIP	2. 7K	5%	1/10W
Q601	8-729-101-07		2SB798-I	DL		R211	1-216-298-00		2. 2	5%	1/10W
Q602	8-729-821-55		2SC3647			R212	1-216-063-00		3. 9K		1/10W
0603	8-729-101-07		2SB798-			R213	1-216-041-00		470	5%	1/10W
Q701	8-729-100-66		2SC1623			R215	1-216-057-00		2. 2K		1/10W
0702	8-729-904-60		DTB1137	K		R216 R218	1-216-061-00		3. 3K	5%	1/10W
0703	8-729-100-66		2SC1623 2SA1162			R219	1-216-075-00 1-216-067-00		12K 5.6K	5%	1/10W
0704	8-729-216-22		2SC3398	-0		R219	1-216-057-00			5% 5%	1/10W
Q705	8-729-805-41		2503336 25A1344			R221	1-216-035-00		2.7K 680	5%	1/10W 1/10W
Q706	8-729-805-65	INANSISION	2381344			1,221	1 210 040 00	MEINE OIII	000	3/4	1/1011
Q707	8-729-805-41	TRANSISTOR	2SC3398			R222	1-216-027-00	METAL CHIP	120	5%	1/10W
Q708	8-729-805-65	TRANSISTOR	2SA1344			R223	1-216-019-00	METAL CHIP	56	5%	1/10W
Q709	8-729-920-34	TRANSISTOR	DTC143X	K		R224	1-216-040-00	METAL GLAZE	430	5%	1/10W
Q710	8-729-821-55	TRANSISTOR	2SC3647	S		R225	1-216-011-00	METAL CHIP	27	5%	1/10W
0711	8-729-821-55	TRANSISTOR	2SC3647	S		R226	1-216-040-00	METAL GLAZE	430	5%	1/10W
0710	8-729-100-66	TDANCICTOD	2SC1623			R227	1-216-025-00	METAL CUID	100	EN	1 /1 0₩
Q712	8-729-100-00		2SB798-			R228	1-216-025-00		100 270	5% 5%	1/10W 1/10W
Q713	0-729-101-07	INANSISION	200130-	UL		R230	1-216-105-00		270 220K	5%	1/10W
		< RESISTOR	`			R234	1-216-035-00		270 270	5%	1/10W
		/ WESTSTON	•			R235	1-216-083-00		27K	5%	1/10W
R101	1-216-093-00	METAL CHIP	68K	5%	1/10W	1200	1 210 000 00	WEINE OIIII	211	3/4	17 1011
R106	1-216-097-00		100K	5%	1/10W	R238	1-216-037-00	METAL CHIP	330	5%	1/10W
R108	1-216-073-00		10K	5%	1/10W	R242	1-216-057-00		2. 2K	5%	1/10W
R109	1-216-073-00		10K	5%	1/10W	R245	1-216-311-00		6. 8	5%	1/10W
R110	1-216-085-00		33K	5%	1/10W	R246	1-216-021-00		68	5%	1/10W
	,				•	R250	1-216-049-00		1 K	5%	1/10W
R112	1-216-089-00	METAL CHIP	47K	5%	1/10W						
R114	1-216-073-00	METAL CHIP	10K	5%	1/10W	R251	1-216-101-00		150K	5%	1/10W
R115	1-216-067-00		5. 6K	5%	1/10W	R252	1-216-105-00		220K	5%	1/10W
R116	1-216-073-00		10K	5%	1/10W	R253	1-216-051-00		1. 2K	5%	1/10W
R117	1-216-097-00	METAL CHIP	100K	5%	1/10W	R301	1-216-081-00		22K	5%	1/10W
R118	1-216-083-00	METAL CHID	27K	5%	1/10W	R302	1-216-029-00	METAL CHIP	150	5%	1/10W
R123	1-216-083-00		18K	5%	1/10W	R303	1-216-081-00	METAL CHIP	22K	5%	1/10W
R125	1-216-071-00		8. 2K	5%	1/10W	R304	1-216-043-00		560	5%	1/10W
R137	1-216-061-00		3. 3K	5%	1/10W	R305	1-216-029-00		150	5%	1/10W
R138	1-216-089-00		47K	5%	1/10W	R306	1-216-051-00		1. 2K	5%	1/10W
11100	1 210 003 00	, meine onii	****	•.•	.,	R308	1-216-027-00		120	5%	1/10W
R139	1-216-073-00	METAL CHIP	10K	5%	1/10W					•	.,
R140	1-216-073-00	METAL CHIP	10K	5%	1/10W	R309	1-216-051-00	METAL CHIP	1. 2 K	5%	1/10W
R141	1-216-105-00	METAL CHIP	220K		1/10W	R310	1-216-065-00	METAL CHIP	4. 7K	5%	1/10W
R146	1-216-065-00	METAL CHIP	4. 7K	5%	1/10W	R311	1-216-073-00		10K	5%	1/10W
R147	1-216-049-06	METAL CHIP	1K	5%	1/10W	R312	1-216-053-00	METAL CHIP	1. 5K	5%	1/10W
						R313	1-216-075-00	METAL CHIP	12K	5%	1/10W
R148	1-216-097-00		100K		1/10W						
R191	1-216-121-07		1M	5%	1/10W	R314	1-216-039-00		390	5%	1/10W
R192	1-216-121-00		1M	5%	1/10W	R315	1-216-085-00		33K	5%	1/10W
R193	1-216-121-00		1M 472	5%	1/10W	R316	1-216-079-00		18K	5%	1/10W
R194	1-216-089-0	WEIAL CHIP	47K	5%	1/10W	R317 R319	1-216-109-00 1-216-055-00		330K 1.8K		1/10W 1/10W
R195	1-216-079-0	O METAL CHIP	18K	5%	1/10W	"""	1 210 000-00	MEINE VIIII	1. OK	J/1	17 1011
R201	1-216-041-0		470	5%	1/10W	R320	1-216-077-00	METAL CHIP	15K	5%	1/10W
R202	1-216-097-0		100K		1/10W	R321	1-216-089-00		47K	5%	1/10W
R203	1-216-093-0		68K	5%	1/10W	R322	1-216-065-00		4. 7K		1/10W
R209		O METAL CHIP	680	5%	1/10W	R323	1-216-091-00		56K	5%	1/10W

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
R324	1-216-077-00	METAL CHIP	15K	5%	1/10W	R421	1-216-001-00	METAL CHIP	10	5%	1/10W
R325	1-216-035-00		270	5%	1/10W	R422	1-216-037-00		330	5%	1/10W
R326	1-216-073-00		10K	5%	1/10W	R427	1-216-097-00		100K		1/10W
R327	1-216-091-00		56K	5%	1/10W	R428	1-216-061-00		3. 3K	5%	1/10W
R328	1-216-081-00		22K	5%	1/10W	R429	1-216-113-00		470K	5%	1/10W
					•					••	.,
R329	1-216-073-00	METAL CHIP	10K	5%	1/10W	R430	1-216-101-00	METAL CHIP	150K	5%	1/10W
R330	1-216-035-00	METAL CHIP	270	5%	1/10W	R431	1-216-033-00	METAL CHIP	220	5%	1/10W
R333	1-216-121-00	METAL CHIP	1M	5%	1/10W	R432	1-216-017-00	METAL CHIP	47	5%	1/10W
R334	1-216-049-00	METAL CHIP	1 K	5%	1/10W	R506	1-216-073-00	METAL CHIP	10K	5%	1/10W
R335	1-216-121-00	METAL CHIP	1M	5%	1/10W	R601	1-216-025-00	METAL CHIP	100	5%	1/10W
R336	1-216-049-00		1 K	5%	1/10W	R602	1-216-031-00		180	5%	1/10W
R337	1-216-121-00	METAL CHIP	1M	5%	1/10W	R603	1-216-073-00	METAL CHIP	10K	5%	1/10W
R338	1-216-049-00	METAL CHIP	1 K	5%	1/10W	R604	1-216-043-00	METAL CHIP	560	5%	1/10W
R339	1-216-104-00	METAL CHIP	200K	5%	1/10W	R605	1-216-083-00	METAL CHIP	27K	5%	1/10W
R340	1-216-085-00	METAL CHIP	33K	5%	1/10W	R606	1-216-069-00	METAL CHIP	6. 8K	5%	1/10W
R342	1-216-043-00		560	5%	1/10W	R608	1-216-009-00		22	5%	1/10W
R343	1-216-043-00		560	5%	1/10W	R609	1-216-051-00		1. 2K		1/10W
R344	1-216-077-00		15K	5%	1/10W	R610	1-216-097-00		100K		1/10W
R345	1-216-077-00		15K	5%	1/10W	R611	1-216-097-00		100K		1/10W
R346	1-216-103-00	METAL CHIP	180K	5%	1/10W	R613	1-216-009-00	METAL CHIP	22	5%	1/10W
R347	1-216-073-00	METAL CHIP	10K	5%	1/10W	R614	1-216-075-00	METAL CHID	12K	5%	1 /1 OW
R348	1-216-748-11		39K	1%	1/10W	R615	1-216-045-00		680	5%	1/10W 1/10W
R350	1-216-043-00		560	5%	1/10W	R616	1-216-097-00		100K	5%	1/10W
R357	1-216-081-00		22K	5%	1/10W	R617	1-216-033-00		220	5%	1/10W
R358	1-216-077-00		15K	5%	1/10W	R618	1-216-083-00		27K	5%	1/10W
					,					•/•	.,
R361	1-216-121-00	METAL CHIP	1M	5%	1/10W	R619	1-216-073-00	METAL CHIP	10K	5%	1/10W
R362	1-216-061-00	METAL CHIP	3. 3K	5%	1/10W	R620	1-216-025-00	METAL CHIP	100	5%	1/10W
R363	1-216-105-00	METAL CHIP	220K	5%	1/10W	R621	1-216-001-00	METAL CHIP	10	5%	1/10W
R364	1-216-105-00	METAL CHIP	220K		1/10W	R622	1-216-001-00	METAL CHIP	10	5%	1/10W
R365	1-216-109-00	METAL CHIP	330K	5%	1/10W	R623	1-216-071-00	METAL CHIP	8. 2K	5%	1/10W
DOCC	1 010 100 00	METAL AULD	2224	F#/	4 /4 614	2004	1 010 005 00				
R366	1-216-109-00		330K	5%	1/10W	R624	1-216-085-00		33K	5%	1/10W
R398	1-216-081-00		22K 2.7K	5% 5%	1/10W 1/10W	R625	1-216-095-00		82K	5%	1/10W
R402 R403	1-216-059-00 1-216-097-00		100K		1/10W	R701 R702	1-216-105-00		220K	5%	1/10W
R405	1-216-113-00		470K		1/10W	R702	1-216-105-00 1-216-073-00		220K	5%	1/10W
N403	1-210-113-00	MEINE CHIF	4101	JA	17 1011	1 1703	1-210-073-00	METAL CHIP	10K	5%	1/10W
R406	1-216-091-00	METAL CHIP	56K	5%	1/10W	R704	1-216-053-00	METAL CHIP	1. 5K	5%	1/10W
	1-216-073-00		10K		1/10W			METAL CHIP			1/10W
R409	1-216-073-00		10K	5%	1/10W	R706	1-216-077-00		15K	5%	1/10W
R410	1-216-073-00		10K	5%	1/10W	R707	1-216-101-00		150K		1/10W
R411	1-216-053-00		1. 5K	5%	1/10W	R708	1-216-258-00		330K		1/8W
									****	••	., •
R412	1-216-748-11		39K	1%	1/10W	R709	1-216-258-00		330K	5%	1/8W
R413	1-216-748-11		39K	1%	1/10W	R710	1-216-174-00		100	5%	1/8W
R414	1-216-089-00		47K	5%	1/10W	R711	1-216-174-00		100	5%	1/8W
R415	1-216-748-11		39K	1%	1/10W	R712	1-216-053-00		1. 5K		1/10W
R416	1-216-748-11	METAL CHIP	39K	1%	1/10W	R713	1-216-097-00	METAL CHIP	100K	5%	1/10W
R417	1-216-009-00	METAL CHIP	22	5%	1/10W	R714	1-216-061-00	METAL CUID	2 24	Ee/	1 /1 OW
R418	1-216-061-00		3. 3K	5%	1/10W	R715	1-216-073-00		3. 3K 10K	5% 5%	1/10W 1/10W
R419	1-216-075-00		12K	5%	1/10W	R716	1-216-081-00		22K	5%	1/10W
R420	1-216-001-00		10	5%	1/10W	R717	1-216-049-00		1 K	5%	1/10W
	. 210 001 00		٠.		.,	"'''		meine VIIII	i N	J/I	1/ 1011

238-716-11 238-716-11 238-715-11 -238-715-11 -238-715-11 -238-715-11 -238-715-11 -228-995-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL	GLAZ GLAZ GLAZ GLAZ GLAZ 22K 47K 47K 47K N 22K 2.2K 47K 47K N 47K N 10K	E 100K E 100K E 100K E 47K E 47K E 47K (BRIG (COLO	HT) UR)		FL70 ND70 SP40 ****
-238-716-11 -238-715-11 -238-715-11 -238-715-11 -238-715-11 -238-715-11 -228-995-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-997-00 -228-996-00 -228-997-00 -228-996-00 -228-997-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL METAL METAL METAL METAL METAL METAL METAL METAL CARBO METAL CARBO METAL METAL METAL METAL METAL	GLAZ GLAZ GLAZ 22K 47K 47K 47K 47K 100K 47K 47K 100K 47K 47K	E 100K E 100K E 47K E 47K E 47K (BRIG (COLO	HT) UR)		ANT10 FL701 ND701 SP401 *****
-238-716-11 -238-715-11 -238-715-11 -238-715-11 -238-715-11 -238-715-11 -228-995-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-997-00 -228-996-00 -228-997-00 -228-996-00 -228-997-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL METAL METAL METAL METAL METAL METAL METAL METAL CARBO METAL CARBO METAL METAL METAL METAL METAL	GLAZ GLAZ GLAZ 22K 47K 47K 47K 47K 100K 47K 47K 100K 47K 47K	E 100K E 100K E 47K E 47K E 47K (BRIG (COLO	HT) UR)		FL70 ND70 SP40 ****
-238-716-11 -238-715-11 -238-715-11 -238-715-11 -228-995-00 -228-996-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL METAL METAL METAL METAL METAL METAL METAL CARBO METAL CARBO METAL METAL METAL METAL METAL METAL	GLAZ GLAZ GLAZ 22K 47K 47K 47K N 47K 2.2K 100K 47K 100K 47K 100K	E 100K E 47K E 47K E 47K (BRIG (COLO	HT) UR)		ND70 SP40 ****
-238-715-11 -238-715-11 -238-715-11 -228-995-00 -228-996-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL METAL METAL METAL METAL METAL METAL CARBO METAL CARBO METAL METAL METAL METAL METAL METAL	GLAZ GLAZ 22K 47K 47K 47K N 47K N 22K 2. 2K 100K 47K 100K 47K 100K	E 47K E 47K E 47K (BRIG (COLO	HT) UR)		\$P40 ****
-238-715-11 -228-995-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-996-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL METAL METAL METAL CARBO METAL METAL METAL METAL METAL METAL	GLAZ 22K 47K 47K 47K 47K N 22K 2. 2K 100K 47K 47K 4. 7K	E 47K (BRIG (COLO	UR)		****
-228-996-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL METAL CARBO METAL CARBO METAL METAL METAL METAL METAL METAL METAL	47K 47K 47K N 47K N 22K 2. 2K 100K 47K N 10K 4. 7K 4. 7K	(BRIG	UR)		
-228-996-00 -228-996-00 -228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. ADJ.	METAL METAL CARBO METAL CARBO METAL METAL METAL METAL METAL METAL METAL	47K 47K 47K N 47K N 22K 2. 2K 100K 47K N 10K 4. 7K 4. 7K	(BRIG	UR)		****
-228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. VER. ADJ.	METAL CARBO METAL CARBO METAL METAL METAL CARBO METAL METAL METAL	47K N 47K N 22K 2. 2K 100K 47K 47K N 10K 4. 7K 4. 7K	(BRIG	UR)		****
-228-996-00 -230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. VER. ADJ.	METAL CARBO METAL CARBO METAL METAL METAL CARBO METAL METAL METAL	47K N 47K N 22K 2. 2K 100K 47K 47K N 10K 4. 7K 4. 7K	(BRIG	UR)		****
-230-498-11 -228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. ADJ. VER. ADJ.	CARBO METAL CARBO METAL METAL METAL CARBO METAL METAL	N 47K 47K 2.2K 2.2K 100K 47K 47K N 10K 4.7K	(COLO	UR)		****
-228-996-00 -230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. ADJ. VER. ADJ. ADJ.	METAL METAL METAL METAL CARBO METAL METAL	47K N 22K 2. 2K 100K 47K 47K N 10K 4. 7K	(COLO	UR)	-	****
-230-722-11 -228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. ADJ. VER. ADJ. ADJ.	METAL METAL METAL METAL CARBO METAL METAL	N 22K 2. 2K 100K 47K 47K N 10K 4. 7K	(VOLU			****
-228-991-00 -228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. ADJ. VER. ADJ. ADJ.	METAL METAL METAL CARBO METAL METAL	2. 2K 100K 47K 47K N 10K 4. 7K	(VOLU			****
-228-997-00 -228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES. RES. RES.	ADJ. ADJ. VER. ADJ. ADJ.	METAL METAL CARBO METAL METAL	47K 47K 47K 10 10K 4. 7K	(VOLU	ME)		****
-228-996-00 -228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES.	ADJ. ADJ. VER. ADJ. ADJ.	METAL METAL CARBO METAL METAL	47K 47K N 10K 4.7K 4.7K	(VOLU	ME)		****
-228-996-00 -241-547-11 -228-993-00 -228-993-00	RES. RES. RES. RES. RES.	ADJ, VER, ADJ, ADJ,	METAL CARBO METAL METAL	. 47K N 10K . 4.7K . 4.7K	(VOLU	ME)		****
-241-547-11 -228-993-00 -228-993-00	RES. RES. RES.	VER, ADJ, ADJ,	METAL METAL	N 10K 4.7K 4.7K	(VOLU	ME)		****
-228-993-00 -228-993-00	RES, RES, RES,	ADJ. ADJ.	METAL	4.7K 4.7K		ME)		****
-228-993-00	RES,	AUJ,	METAL	. 4. / 1				
	RES,							
-228-993-00		ADJ.	METAL					1
	/ cwi			. 4.7K				#1
	\ on	TCH	>					#2
-554-061-00	SWIT	H. S	LIDE	(BAND)				#3
-554-303-21	SWITC	H. T	ACTILE	(TUN	IING -)			#5
-554-303-21 -554-303-21	1 SWITC	H, T	ACTILE	(TUN	IING +)			
-554-303-21	1 SWITC	:н, т	ACTILE	(CH	CALL)			
-554-061-00	SWIT	CH, S	LIDE	(POWER	₹)			
	< FII	TER	>					
-577-604-11	1 FILTI	R, S	AW (38	3. 9MH	2)			
	< TR	ANSFO	RMER :	>				
-459-949-11	1 COIL							
-450-286-11	1 TRANS	SFORM	IER, DO	C-AC (CONVERT	ER		1
	< TU	NER U	JNIT >					
-466-590-11	1 TUNE	R UNI	ΙΤ					
	< CR	YSTAI	>					
FC7 FA4 A4				VCTAI	(4 40) C 1 () JU - \		
1-501-504-8	1 0201	LLAI	JR, CK	ISIAL	(4. 43)	OUISMUZ)		
	-459-949-1 -450-287-1 -450-286-1 -466-590-1	-577-604-11 FILTE < TR/ -459-949-11 COIL -450-287-11 TRANS -450-286-11 TRANS < TUI -466-590-11 TUNES	-577-604-11 FILTER, S < TRANSFO -459-949-11 COIL -450-287-11 TRANSFORM -450-286-11 TRANSFORM < TUNER UNI -466-590-11 TUNER UNI < CRYSTAL	<pre></pre>	-577-604-11 FILTER, SAW (38.9MHz < TRANSFORMER > -459-949-11 COIL -450-287-11 TRANSFORMER, DC-DC (-450-286-11 TRANSFORMER, DC-AC (< TUNER UNIT > -466-590-11 TUNER UNIT < CRYSTAL >	-577-604-11 FILTER, SAW (38.9MHz) < TRANSFORMER > -459-949-11 COIL -450-287-11 TRANSFORMER, DC-DC CONVERT -450-286-11 TRANSFORMER, DC-AC CONVERT < TUNER UNIT > -466-590-11 TUNER UNIT < CRYSTAL >	-577-604-11 FILTER, SAW (38.9MHz) < TRANSFORMER > -459-949-11 COIL -450-287-11 TRANSFORMER, DC-DC CONVERTER -450-286-11 TRANSFORMER, DC-AC CONVERTER < TUNER UNIT > -466-590-11 TUNER UNIT < CRYSTAL > 1-567-504-81 OSCILLATOR, CRYSTAL (4.433619MHz)	-577-604-11 FILTER, SAW (38.9MHz) < TRANSFORMER > -459-949-11 COIL -450-287-11 TRANSFORMER, DC-DC CONVERTER -450-286-11 TRANSFORMER, DC-AC CONVERTER < TUNER UNIT > -466-590-11 TUNER UNIT

lef. No.	Part No.	Description	Remark
		MISCELLANEOUS	

ANT 101	1-501-494-11	ANTENNA, TELESCOPIC	
L701	1-519-563-11	INDICATOR TUBE. FLUORESCE	NT
		DISPLAY MODULE. LIQUID CR	
		SPEAKER (8CM)	
******	******	*********	******
	ACCESSORIE	S & PACKING MATERIALS	
	*******	******	
<u> </u>	. 1-465-817-11	ADAPTOR, AC (AC-E702AE)	
	1-558-949-11	CABLE, ANTENNA	
	3-754-010-11	MANUAL, INSTRUCTION	
		(ENGLISH, FRENCH, GERMAN, DU	ITCH, SWEDISH)
*	4-030-767-01	CUSHION (UPPER)	·
*	4-030-768-01	CUSHION (LOWER)	
		INDIVIDUAL CARTON	
•		BAG. PROTECTION	

HARDWARE LIST

#1	7-682-547-04	SCREW	+B 3X6	
#2	7-685-646-79	SCREW	+BVTP	3X8 TYPE2 N-S
#3	7-685-647-79	SCREW	+BVTP	3X10 TYPE2 N-S
#4	7-685-649-79	SCREW	+BVTP	3X14 TYPE2 N-S
#5	7-685-105-19	SCREW	(2X8), +	PTPWH

Note: The components identified by mark \bigwedge or dotted line with mark \bigwedge are critical for safety. Replace only with part number specified.